

Directions for the Easy Footer

Put the Easy Footer on the booms it hangs down right by the inside boom cable. Only use a BI Boom for safety. Before taking off, with someone in the Easy Footer, make sure that the boom is at the right height so that the handle of the Easy Footer is hovering about an inch out of the water when the person is sitting in it. It may take a couple of times, having the person climb in and out to get it adjusted like this, but it is important that you do. With a very young child, with short arms, you will have to roll the Easy Footer around the boom so their hands can easily reach the boom to hold on. Then regardless of the size and weight of the person, only go between 10 and 20 MPH. The person in the Easy Footer should try to keep their feet on the water without feeling like their toes are going to catch, the better glide they will get and the better barefooter they become.